

Serie IOP / IOM - 3K-24

Service manual



Serie IOP / IOM - 3K-24 Service manual

Revision	Description	Prepared by	Approved by
V00	Initial draft release	Zhaohui_Xu 2016-4-01	
V01		Eric Chen 2022-7-27	

Table of contents

1.	General information	4
1.1	Getting start	4
1.2	Important safety instructions	4
2.	Functional block	6
3.	Working principle of the major functional block	7
3.1	Switch Power Supply	7
3.2	DC TO DC converter (push-pull)	8
3.3	DC TO AC inverter (full-bridge)	9
3.4	Charger	10
4.	Functional explanations for each PCB	11
4.1	Main board	11
4.2	SCC board	11
4.3	COMM board	11
4.4	LED board	11
5.	Interface	12
5.1	LED Indicator	12
5.2	LCD Display Icons	13
6.	Troubleshooting	17
6.1	Fault Reference Code	17
6.2	Warning Indicator	17
6.3	Trouble shooting according to fault indication	18
6.4	Quick start	19
7.	Test Step	21
8.	Electrical specification	22
	Table 1 Line Mode Specifications	22
	Table 2 Invert Mode Specifications	23
	Table 3 Charge Mode Specifications	24
	Table 4 General Specifications	

1. General information

1.1 Getting start

This manual is for NRG IOP / IOM 3K-24 series, it can help service personal perform the basic maintenance and repair service.

This manual focus on the service, so you should get the basic operation of the Inverter/Charger from the user manual, and make sure you had read and understood user manual before you use this service manual.

The manual include 8 sections, as follows

- General Information, this section show you the general information of the service manual
- Functional Block, this section show you the major functional block of the Inverter/Charger
- Working Principle of the major Functional Block, this section show you the major functional block
- Function explanations for each PCB, this section show you all the PCBs of the Inverter/Charger
- Interface, this section show you the LCD interface, include display and setting
- Trouble shooting, this section will give you the way to find the trouble
- Test step ,this section tell you how to test the Inverter/Charger after you repair the unit
- Electric Specifications, this section show you the basic electric specification of the Inverter/Charger

1.2 Important safety instructions



WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

1. Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
2. **CAUTION** --To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
3. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. **CAUTION** – Only qualified personnel can install this device with battery.
6. **NEVER** charge a frozen battery.
7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to

drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.

9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
10. One piece of fuse(150A, 32VDC) are provided as over-current protection for the battery supply.
11. GROUNDING INSTRUCTIONS -This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. NEVER cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
13. **Warning!!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.

2. Functional block

NRG IOP / IOM 3K-24 series production employ a double conversion topology, comprise following functional blocks, as shown in figure 2.1





Figure 2.1 function block diagram

3. Working principle of the major functional block

3.1 Switch Power Supply

The switch power supply (SPS) supplies DC power for Inverter/Charger operation. The input voltage of the SPS is the battery or AC Charger output voltage.



3.2 DC TO DC converter (push-pull)

The push-pull topology is a transformer isolated forward-mode regulator. Unlike the Fly-back transformer, the push-pull transformer does not store any energy and output current is drawn when either power switches (Q7-Q10 or Q2-Q5) is conducting.

A push-pull topology is shown in figure 3.2, power switch Q7-Q10 and Q2-Q6 receive 180 out-of-phases. Refer to figure 3.2, the battery voltage is transformed through a push-pull DC-DC converter to >330Vdc as DC BUS for inverter. When the line fails, the DC BUS voltage is caught up to supply the power needed by the inverter immediately.

The output voltage (DCBUS) must be higher than the input voltage (BAT+) .It mentioned by the primary turns and secondary turns. In this circuit, BAT+ = 24V,DC BUS voltage above 330Vdc.




Figure 3.2 Push-pull topology

3.3 DC TO AC inverter (full-bridge)

The Inverter circuit (Figure 3.3) and PWM control are only active under battery mode. The Inverter circuit of NRG IOP / IOM 3K-24 series series is based on a full-bridge circuitry and its output is driven by photo-couplers. The photo-couplers are capable to drive high energy and high speed power of MOSFET and IGBT with independent high and low referenced output channels. To construct a high frequency PWM inverter, the drivers receive switching signals from PWM generation circuit through a pair of photo-couplers to trigger the upper IGBT and the lower IGBT alternately. The output of IGBT's is filtered by an LC circuit to reduce the o/p voltage harmonics distortion.




Figure 3.3 Full-bridge topology

3.4 Charger

The Charger of utility is to recharge and maintain the batteries at fully charged condition .The charger charges the batteries with a constant current at initial stage, and as battery voltage keep increasing, the charge current decrease accordingly until the charge voltage reached the constant voltage level, and then the charger turn to the floating charge mode.

As shown in figure 3.4, the charger also employed a fly-back topology like the SPS.




Figure 3.4 Charger fly-back topology

4. Functional explanations for each PCB

Item	Series name	PCB name	PCB serial number	Quantity	Remark
1	IOP-3K-24	Main	71-500937-XXG	1	
2		SCC	71-500654-XXG	1	
3		LED	71-500238-XXG	1	
4	IOM-3K-24	Main	71-500936-XXG	1	
5		SCC	71-500656-XXG	1	
6		LED	71-500238-XXG	1	

Note: "XX" in the serial number is the version of the PCB.

4.1 Main board

The main board consists of SPS, DC-DC converter, inverter, charger, MCU control. Many semiconductors and easy-failure components on the board, so it should be pay more attention when the system is abnormal.

4.2 SCC board

The solar current control (SCC) board based on a PWM control mode for IOP-3K-24 and a MPPT control mode for IOM-3K-24 .When the solar source is presented, battery charged from solar source; MAX charge current is 50A@ IOP-3K-24 and 40A@ IOM-3K-24, if solar panel with enough energy.

4.3 COMM board


This inverter/charger is equipped with a communication port to communicate with a PC with corresponding software. Please use supplied communication cable to connect to communication port of this inverter and USB port of the PC.

4.4 LED board




The LED display panel includes there indicators and four functional keys.

5. Interface

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LCD display, indicating the operating status and input/output power information.




5.1 LED Indicator










LED Indicator			Messages
	Green	Solid On	Output is available in bypass mode
		Flashing	Output is powered by battery in inverter mode
	Green	Solid On	Battery is fully charged
		Flashing	Battery is charging.
	Red	Solid On	Fault mode
		Flashing	Warning mode

Function Keys

Function Key	Description
ESC	Exit setting mode
UP	To previous selection
DOWN	To next selection
ENTER	To confirm the selection in setting mode or enter setting mode









5.2 LCD Display Icons









Icon	Function description	
Input Source Information		
	Indicates the AC input.	
	Indicates the PV input	
	Indicate input voltage, input frequency, PV voltage, charger current (if PV in charging for 3K models), charger power (only for MPPT models), battery voltage.	
Configuration Program and Fault Information		
	Indicates the setting programs.	
	Indicates the warning and fault codes. Warning:  flashing with warning code. Fault:  lighting with fault code	
Output Information		
	Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current.	
Battery Information		
	Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode.	
In AC mode, it will present battery charging status.		
Status	Battery voltage	LCD Display
Constant	<2V/cell	4 bars will flash in turns.
Current mode /	2 ~ 2.083V/cell	Bottom bar will be on and the other three bars will flash in turns.

Constant Voltage mode	2.083 ~ 2.167V/cell	Bottom two bars will be on and the other two bars will flash in turns.	
	> 2.167 V/cell	Bottom three bars will be on and the top bar will flash.	
Floating mode. Batteries are fully charged.		4 bars will be on.	






In battery mode, it will present battery capacity.

Load Percentage	Battery Voltage	LCD Display
Load >50%	< 1.85V/cell	
	1.85V/cell ~ 1.933V/cell	
	1.933V/cell ~ 2.017V/cell	
	> 2.017V/cell	
Load < 50%	< 1.892V/cell	
	1.892V/cell ~ 1.975V/cell	
	1.975V/cell ~ 2.058V/cell	
	> 2.058V/cell	











Load Information

	Indicates overload.			
	Indicates the load level by 0-24%, 25-50%, 50-74% and 75-100%.			
	0%~25%	25%~50%	50%~75%	75%~100%
				









Mode Operation Information

	Indicates unit connects to the mains.
	Indicates unit connects to the PV panel.
	Indicates load is supplied by utility power.
	Indicates the utility charger circuit is working.
	Indicates the DC/AC inverter circuit is working.







Mute Operation

	Indicates unit alarm is disabled.	
Icon	Function description	
Input Source Information		
	Indicates the AC input.	
	Indicates the PV input	
	Indicate input voltage, input frequency, PV voltage, battery voltage and charger current.	
Configuration Program and Fault Information		
	Indicates the setting programs.	
	Indicates the warning and fault codes.	
	Warning:  flashing with warning code.	
	Fault:  lighting with fault code	
Output Information		
	Indicate output voltage, output frequency, load percent, load in VA and load in Watt.	
Battery Information		
	Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode.	
In AC mode, it will present battery charging status.		
Status	Battery voltage	LCD Display
Constant Current mode / Constant Voltage mode	<2V/cell	4 bars will flash in turns.
	2 ~ 2.083V/cell	Bottom bar will be on and the other three bars will flash in turns.
	2.083 ~ 2.167V/cell	Bottom two bars will be on and the other two bars will flash in turns.
	> 2.167 V/cell	Bottom three bars will be on and the top bar will flash.
Floating mode. Batteries are fully charged.		4 bars will be on.





In battery mode, it will present battery capacity.

Load Percentage	Battery Voltage	LCD Display
Load > 50%	< 1.85V/cell	
	1.85V/cell ~ 1.933V/cell	
	1.933V/cell ~ 2.017V/cell	
	> 2.017V/cell	
Load < 50%	< 1.892V/cell	
	1.892V/cell ~ 1.975V/cell	
	1.975V/cell ~ 2.058V/cell	
	> 2.058V/cell	


Load Information

OVER LOAD	Indicates overload.			
 	Indicates the load level by 0-24%, 25-50%, 50-74% and 75-100%.			
	0%~25%	25%~50%	50%~75%	75%~100%
				

Mode Operation Information

	Indicates unit connects to the mains.
	Indicates unit connects to the PV panel.
BYPASS	Indicates load is supplied by utility power.
	Indicates the utility charger circuit is working.
	Indicates the DC/AC inverter circuit is working.

Mute Operation

	Indicates unit alarm is disabled.
---	-----------------------------------










6. Troubleshooting

This section describes how to find the trouble when the system is abnormal. We suggest you can follow the service procedure:



- Check the system status by LED and LCD display, the sounds of buzzer.
- Observe the failure board, static checking.
- Replace the failure components.
- Static checking.
- Power up checking.
- Test after repair.




Following section will help service person to solve most of problem.

6.1 Fault Reference Code

Fault Code	Fault Event	Icon on
01	Fan is locked when inverter is off.	
02	Over temperature	
03	Battery voltage is too high	
04	Battery voltage is too low	
05	Output short circuited or over temperature is detected by internal converter components.	
06	Output voltage is abnormal. (For 3KVA model) Output voltage is too high. (For 3KVA Plus/5KVA model)	
07	Overload time out	
08	Bus voltage is too high	
09	Bus soft start failed	

6.2 Warning Indicator

Warning Code	Warning Event	Audible Alarm	Icon flashing
01	Fan is locked when inverter is on.	Beep three times every second	
03	Battery is over-charged	Beep once every second	

04	Low battery	Beep once every second	
07	Overload	Beep once every 0.5 second	 OVER LOAD
10	Output power derating	Beep twice every 3 seconds	

6.3 Trouble shooting according to fault indication

Problem	LCD/LED/Buzzer	Explanation / Possible cause	What to do
Unit shuts down automatically during startup process.	LCD/LEDs and buzzer will be active for 3 seconds and then complete off.	The battery voltage is too low (<1.91V/Cell)	1. Re-charge battery. 2. Replace battery.
No response after power on.	No indication.	1. The battery voltage is far too low. (<1.4V/Cell) 2. Internal fuse tripped.	1. Contact repair center for replacing the fuse. 2. Re-charge battery. 3. Replace battery.
Mains exist but the unit works in battery mode.	Input voltage is displayed as 0 on the LCD and green LED is flashing.	Input protector is tripped	Check if AC breaker is tripped and AC wiring is connected well.
	Green LED is flashing.	Insufficient quality of AC power. (Shore or Generator)	1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS→Appliance)
	Green LED is flashing.	Set "Solar First" as the priority of output source.	Change output source priority to Utility first.
When the unit is turned on, internal relay is switched on and off repeatedly.	LCD display and LEDs are flashing	Battery is disconnected.	Check if battery wires are connected well.
Buzzer beeps continuously and red LED is on.	Fault code 07	Overload error. The inverter is overload 110% and time is up.	Reduce the connected load by switching off some equipment.
	Fault code 05	Output short circuited.	Check if wiring is connected well and remove abnormal load.
		Temperature of internal converter component is over 120°C. (Only available for 1-3KVA models)	Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
	Fault code 02	Internal temperature of inverter component is over 100°C.	
	Fault code 03	Battery is over-charged.	Return to repair center.
		The battery voltage is too high.	Check if spec and quantity of batteries are meet requirements.

	Fault code 01	Fan fault	Replace the fan.
	Fault code 06/58	Output abnormal (Inverter voltage below than 190Vac or is higher than 260Vac)	1. Reduce the connected load. 2. Return to repair center
	Fault code 08/09/53/57	Internal components failed.	Return to repair center.
	Fault code 51	Over current or surge.	Restart the unit, if the error happens again, please return to repair center.
	Fault code 52	Bus voltage is too low.	
	Fault code 55	Output voltage is unbalanced.	
	Fault code 56	Battery is not connected well or fuse is burnt.	If the battery is connected well, please return to repair center.

6.4 Quick start


Before any detail check of the system, please check the components listed as follow table.

NOTE: It is important to check the capacitor's voltage on the board lower than the safety voltage before any check action.

Functional block	Checked components		Instruction function	Reference value	Failed status
DC-DC Converter	Fuse	F1	Resistance	0.14 ohm	short or open
	MOSFET(TK100E08N1)	Q2---Q10	Resistance	310k DS	short or open
				290k GD	short or open
				5k GS	short or open
	Diode(NXP/BYC15-600P)	D17---D20	Resistance	165k	short or open
	Resistance	R6---R14	Resistance	10 ohm	short or open
DC-AC Inverter	IGBT(IRGP/4063DPBF)	Q16---Q19	Resistance	178K-200K DS	short or open
				220K-250K GD	short or open
				50K GS	short or open
	Resistance	R54,R56,R61,R64	Resistance	100 ohm	short or open
	Photo-coupler	U24---U27	Resistance	2K	short or open
Charger	Rectifier	REC1	Resistance	0.5M PIN1-PIN2	short or open
				0.43M PIN1-PIN3	short or open
				160K PIN1-PIN4	short or open
	MOSFET(2SK3878)	Q20---Q22	Resistance	162K DS	short or open
				210K GD	short or open
				12K GS	short or open

	Diode(MBR20200)	D21---D23	Resistance	>4M	K->A	short or open
			Resistance	78K	A->K	short or open
	Control IC	UC3843	Resistance	>4K	PIN5-PIN7	short or open
	Resistance	R258,R260,R262	Resistance	100 ohm		short or open
S.P.S	Control IC	UC3845	Resistance	>4K	PIN5-PIN7	short or open
	Diode	D2,D3,D32,D34	Resistance	>4K		short or open
		D1	Resistance	3.5K		short or open
	Resistance	R31,R99	Resistance	2.2 ohm		short or open
S.C.C(IOP-3K-24)	MOSFET(IRFB3306GPBF)	Q46---Q51	Resistance	>230K	DS	short or open
				0.7M	GD	short or open
				0.45M	GS	short or open
	Op07 Amp	U1 PIN8-PIN4	Resistance	>30K		short or open
	MCU	U7 PIN17-PIN16	Resistance	>0.8K		short or open
	Transistor	Q40、Q43	Resistance	>85K	BE	short or open
				>0.4M	EC	short or open
				>0.4M	BC	short or open
	Transistor	Q12、Q44	Resistance	10K	BE	short or open
				>280K	EC	short or open
				>280K	BC	short or open
MPPT(IOM-3K-24)	MOSFET(IRFB4410)	Q14、Q44、Q45	Resistance	>230K	DS	short or open
				0.7M	GD	short or open
				0.45M	GS	short or open
	Op07 Amp	U1 PIN8-PIN4	Resistance	>30K		short or open
	MCU	U7 PIN17-PIN16	Resistance	>0.8K		short or open
	Transistor	Q50	Resistance	>85K	BE	short or open
				>0.4M	EC	short or open
				>0.4M	BC	short or open
	Resistance	R374、R375、R376	Resistance	2.2 ohm		short or open
						short or open
						short or open

7. Test Step



8. Electrical specification

Table 1 Line Mode Specifications



INVERTER MODEL	3KVA
Input Voltage Waveform	Sinusoidal (utility or generator)
Nominal Input Voltage	230Vac
Low Loss Voltage	170Vac \pm 7V (UPS); 90Vac \pm 7V (Appliances)
Low Loss Return Voltage	180Vac \pm 7V (UPS); 100Vac \pm 7V (Appliances)
High Loss Voltage	280Vac \pm 7V
High Loss Return Voltage	270Vac \pm 7V
Max AC Input Voltage	300Vac
Nominal Input Frequency	50Hz / 60Hz (Auto detection)
Low Loss Frequency	40 \pm 1Hz
Low Loss Return Frequency	42 \pm 1Hz
High Loss Frequency	65 \pm 1Hz
High Loss Return Frequency	63 \pm 1Hz
Output Short Circuit Protection	Circuit Breaker
Efficiency (Line Mode)	>95% (Rated R load, battery full charged)
Transfer Time	10ms typical (UPS); 20ms typical (Appliances)
Output power derating: When AC input voltage drops to 170V, the output power will be derated.	 <p>The graph illustrates the output power derating characteristics of the inverter. The vertical axis represents Output Power, with markers for Rated Power and 50% Power. The horizontal axis represents Input Voltage, with markers at 90V, 170V, and 280V. The power remains at the Rated level until the input voltage drops to 170V. Below 170V, the power derates linearly, reaching 50% of the Rated Power at 90V. From 90V to 280V, the output power remains constant at 50% of the Rated Power.</p>

Table 2 Invert Mode Specifications

INVERTER MODEL	3KVA
Rated Output Power	3KVA/3KW
Output Voltage Waveform	Pure Sine Wave
Output Voltage Regulation	230Vac±5%
Output Frequency	50Hz
Peak Efficiency	93%
Overload Protection	5s@≥150% load; 10s@105%~150% load
Surge Capacity	2* rated power for 5 seconds
Nominal DC Input Voltage	24Vdc
Cold Start Voltage	23.0Vdc
Low DC Warning Voltage @ load < 50% @ load ≥ 50%	23.0Vdc 22.0Vdc
Low DC Warning Return Voltage @ load < 50% @ load ≥ 50%	23.5Vdc 23.0Vdc
Low DC Cut-off Voltage @ load < 50% @ load ≥ 50%	21.5Vdc 21.0Vdc
High DC Recovery Voltage	32Vdc
High DC Cut-off Voltage	33Vdc
No Load Power Consumption	<25W

Table 3 Charge Mode Specifications

Utility Charging Mode		
INVERTER MODEL		3KVA
Charging Algorithm		3-Step
AC Charging Current (Max)		25Amp (@V _{I/P} =230Vac)
Bulk Charging Voltage	Flooded Battery	29.2
	AGM / Gel Battery	28.2
Floating Charging Voltage		27Vdc
Charging Curve		

PWM Solar Charging Mode	
INVERTER MODEL	IOP-3K-24
Charging Current	50Amp
System DC Voltage	24Vdc
Operating Voltage Range	30~32Vdc
Max. PV Array Open Circuit Voltage	80Vdc
DC Voltage Accuracy	+/-0.3%
Max Charging Current (AC charger plus solar charger)	70Amp
MPPT Solar Charging Mode	
INVERTER MODEL	IOM-3K-24
Charging Current	40Amp
PV Array MPPT Voltage Range	30~80Vdc
Max. PV Array Open Circuit Voltage	102Vdc
Max Charging Current (AC charger plus solar charger)	60Amp